



# Range Rover P38 Side Steps

Fitting Instructions (PM404)

---



1. Fit the four brackets to the chassis; they are not handed. The fixing holes are pre-drilled by the factory and located in the side of the chassis approximately below the centre of each door.
2. Now attach one of the side steps to the brackets with one bolt in the back of the front and rear legs leaving the step hanging. Use a flat washer either side of the bolts and a spring washer under the nut.
3. Swing the step up in to place and fit the second pair of bolts, complete with washers.
4. Adjust step for best horizontal fit and tighten nuts and bolts fully.
5. If your vehicle does not already have mud flaps, fit front mud flap using the screws supplied. Two top screws fit through the edge of the wing arch, use the spring 'd' clips provided for the top holes (if there are none already fitted by the factory). The lower screw goes through the hole in the mud flap and self taps itself into step. Adjust mud flap for best fit, tighten all bolts. Apply load.

Your steps are now ready.