



Rear Shock Fitment For Defender TD5/Puma/300TDI Disco

1. Insert washer onto bottom peg upside down.
2. Then insert rubber bush narrow end first.
3. Then insert shock into axle mount, making sure bush locates into axle cup mount.
4. Insert rubber bush onto shock wide end first and confirm that it locates into axle cup mount.
5. Insert washer upside down.
6. Insert nut and tighten nut so 10mm of thread is showing.
DO NOT OVER TIGHTEN

These instructions are for the bottom of the rear shocks only.
The fitment of the front and rear top are as normal fitment

