

# Defender Glove Box Kit

# BRITPART

The quality parts for Land Rovers

## FITTING INSTRUCTIONS

Part Number - DA2603



1. Remove panel bolts



2. Remove clips and styrofoam



3. Cut excessive pins with sharp knife



4. Remove grab handle



5. Put mounting plate in position and bolt down



6. Mount front panel (5 screws)



7. Attach glove box cover to mounting plate



### Disclaimer

These fitting instructions are intended for general guidance only. No responsibility will be accepted for damage to persons, property, equipment or vehicles caused during or arising from the fitment or using of this product. Fitting this item to your vehicle may constitute a vehicle modification and therefore we strongly recommend that you check the product complies with local laws and legislation and always inform the vehicle's insurance company accordingly.

Vr: 1

