Defender 90 Side Steps

BRITPART

The quality parts for Land Rovers

FITTING INSTRUCTIONS

DA4101



Contents

1 x Left hand side step

1 x Right hand side step

2 x Slotted washers

2 x M10 x 35 bolts with nuts and washers

2 x M8 x 25 bolts with nuts and washers

Instructions

1 Remove nut and washer from front chassis outrigger.

2 Fit side step with single hole end to front of vehicle over outrigger bolt.

3 Lift rear of step to align with chassis mounting holes.

4 Use heavy slotted washer over square chassis hole

5 Check step for correct alignment and fully tighten all mounting bolts ensuring front outrigger bolt is tightened to 111Nm.

Disclaimer
These fitting instructions are intended for general guidance only. No responsibility will be accepted for damage to persons, property, equipment or vehicles caused during or arising from the fitment or using of this product. Fitting this item to your vehicle may constitute a vehicle modification and therefore we strongly recommend that you check the product complies with local laws and legislation and always inform the vehicle's insurance company accordingly.