

# **Fitting Instructions**

- 1 INSURE THAT THE SURFACE WHICH THE PRODUCT IS TO BE APPLIED IS CLEAN, DRY AND FREE OF ALL OIL, GREASE AND WAX.**
- 2 DETERMINE EXACT LOCATION OF PRODUCT.**
- 3 REMOVE PROTECTIVE FILM FROM ADHESIVE, ALIGN CAREFULLY AND THEN PRESS FIRMLY TO ENSURE PROPER ADHESION.**
- 4 DO NOT MOVE THE PRODUCT OR WASH VEHICLE WITHIN 24 HOURS AFTER INSTALLATION.**