

SSW100080
SSW100090

BRITPART

The quality parts for Land Rovers

IMPORTANT INFORMATION

Once the old sensor has been removed the sensor hole must be thoroughly cleaned out.

The fit of the new sensor must be done by hand. Once the hole is clear of any rust or burrs the greased sensor should be a push fit.

If it is not possible to insert the new sensor by hand the hole must undergo further cleaning.

In many cases this will necessitate using some wet & dry sand paper to remove any rust or burrs present.

UNDER NO CIRCUMSTANCES SHOULD THE SENSOR BE TAPPED INTO PLACE WITH A WOODEN BLOCK, HAMMER etc.....

Disclaimer

