

Fitting Instructions



Using the 8mm bolts provided attach the brackets to the A bar. Small brackets to the top, short angle to the bolt end. Long curved brackets to the bottom of the A bar.

Open the bonnet and remove the two screws from either side of the slam panel. Remove the two 13mm chassis bolts from either side of the front cross member just under the lower plastic skirt.

Offer up the A bar to the front of the car and fix the top two brackets, using the long screws provided.
Fix the lower brackets into the holes left from the bolts you removed earlier.

Adjust the A bar for fit before tightening all fixings.