



VEHICLE FIT ROOF RACK ACCESS LADDER FITTING INSTRUCTIONS

- 1. REMOVE THE TWO LEFT HAND SIDE REAR CROSS MEMBER BOLTS.**
- 2. APPLY SELF ADHESIVE SPONGE TO DRIP RAIL.**
- 3. HOOK ACCESS LADDER ONTO DRIP RAIL.**
- 4. FIX BOTTOM BRACKET USING THE TWO CROSS MEMBER BOLTS, AT THE POINT OF THE BOLTS TIGHTENING THEN PULL DOWN ON THE LADDER TO SECURE IN PLACE. CONTINUE TO TIGHTEN THE BOLTS**